



Attention




Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.

Note:



Tips for facilitation of operation, control and adjustment, as well as maintenance work.



TOOLS REQUIRED:
Torx Wrench, T25



Right and left side of motorcycle is determined while sitting on the bike.

PARTS LIST

<u>Index</u>	<u>Description</u>	<u>Qty.</u>
1	VStream® Windscreen, Quantum Hardcoated Polycarbonate	1

INSTALLATION



Retain all fasteners, as they will be reused.

1. Remove the 6 screws holding the outside plates on stock windshield. **(Torx Wrench, T25)**
2. Remove stock windscreen.
3. Reinstall the stock outside plates onto your new VStream windshield using stock screws. **(Torx Wrench, T25)**
4. Tighten the bolts firmly. **(Torx Wrench, T25)**

MAINTENANCE

Cleaning: Wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths.

View ZTechnik® K 1200 GT products at
www.ZTechnik.com

CARBON FIBER • EXHAUST SYSTEMS • STORAGE POD
TECHMOUNT MOUNTS